



Intertek

Control # 5023603
Conforms To UL STD 514D
Certified To CSA STD C22.2 # 42.1

Hide-A-Trim

FLUSH MOUNTED SOLUTIONS

Installation Instructions
FOR
Adjustable Kit for Wood Surface

PLEASE WATCH INSTALLATION ON OUR WEBSITE www.hideatrim.com



This Kit is designed to be installed by:

First: The electrician's job is to receive the kit(s), inspect the kit for correct contents, and give the template and faceplate to the construction supervisor/manager.

Second: Cabinet Maker

ELECTRICIAN:

Install the wiring in the Raco Box.

Adhere the Raco box to the base bracket by removing the protective tape. Wire the electrical device and screw into the Raco box. Place the protection plate on the base plate.

CABINET MAKER:

Make an opening to receive the adjustable kit.

Use the supplied Gorilla Glue to adhere the base plate to the backside of the wooden surface. Install the provided wood screws.

LEVELING RECOMMENDATION: Loosen the four outer leveling screws. Adjust the inner screws with the supplied TORX wrench to the desired level by pushing them down on the protection plate. Tighten the outer screws to keep level.

Remove the protection plate and replace it with the required finishing face plate.

NOTE: If a custom finish is required, take pictures as outlined on our website. Keep a sample of the tile and the cutout piece. Fill out the form on www.hideatrim.com

Send the sample to the following address:

Hide-A-Trim
Nassco Products LLC
2460 NW 17th Ln, Unit 4
Pompano Beach FL 33064